

<http://www.lada.co.uk>

Lada Niva 4x4  
Service Manual  
Fuel Injection

You use the information contained with this manual at you own risk. If you're not sure how to do something either don't do it or ask someone who knows about such things. The font of all Lada knowledge can be found at:

<http://www.lada.co.uk/forum>

For Lada parts, advice and general all round Lada wonderfulness these blokes aren't bad:

Contact

Tom Grealey

[tom@lada.co.uk](mailto:tom@lada.co.uk)

CONTENTS

Introduction .....	2	Steering Rods and Ball Joints .....	122
Section I. General Data		Idler Arm Bracket .....	122
Specifications .....	3	Section VI. Brakes	
Main Adjustment and Check Data .....	5	Trouble Shooting .....	124
Fuels, Lubricants and Fluids .....	5	Checks and Adjustment .....	126
Section II. Engine		Clutch and Brake Pedal Bracket .....	130
Trouble Shooting .....	8	Vacuum Booster .....	131
Engine Removal and Installation .....	11	Brake Master Cylinder .....	131
Engine Disassembly .....	12	Front Brakes .....	132
Engine Assembly .....	14	Rear Brakes .....	134
Engine Stand Tests .....	17	Rear Brake Pressure Regulator .....	136
Engine Checkover on Car .....	17	Parking Brake .....	138
Cylinder Block .....	17	Section VII. Electrical Equipment	
Pistons and Connecting Rods .....	19	General .....	138
Crankshaft and Flywheel .....	23	Storage Battery .....	140
Cylinder Head and Valve Gear .....	25	Alternator .....	142
Camshaft and Drive .....	29	Voltage Regulator .....	147
Cooling System .....	32	Battery No-Charge Warning Lamp Relay .....	150
Lubricating System .....	35	Starter .....	150
Crankcase Breathing System .....	38	Ignition System .....	155
Fuel System .....	39	Lighting and Light Signalling System .....	160
Exhaust System .....	52	Horns .....	164
Section III. Power Train		Windshield Wiper .....	164
Clutch .....	53	Headlight Wiper .....	167
Gearbox .....	59	Heater Motor .....	167
Transfer Case .....	70	Instruments .....	168
Propeller Shaft Drive .....	77	Section VIII. Body	
Rear Axle .....	81	Trouble Shooting .....	173
Front Axle .....	95	Body and Its Elements .....	174
Front Wheel Drive .....	97	Body Paint Coating .....	178
Section IV. Running Gear		Anticorrosive Treatment of Body .....	179
Trouble Shooting .....	100	Doors .....	183
Front Suspension .....	102	Hood, Bumpers .....	186
Rear Suspension .....	110	Window Glasses, Windshield and Headlight	
Shock Absorbers .....	112	Washers .....	187
Section V. Steering Gear		Instrument Panel .....	189
Trouble Shooting .....	115	Seats .....	190
Inspection, Checks and Adjustment .....	117	Heater .....	190
Steering Mechanism .....	118		